16" Heavy Duty Surface Spinner



Operation and Maintenance Manual

Table of Contents

Introduction Page 3 Safety Pages 4 & 5 Specifications Page 6 Setup and Operating Information Pages 7 - 12 Routine Maintenance Page 13 Trouble Shooting Guide Pages 14 & 15 Illustrated Parts List Pages 16 - 19 Reference Pages 20 & 21 Notes Page 22 Warranty Page 23

Introduction

To the Owner:

CONGRATULATIONS

You have just purchased the finest piece of cleaning equipment available, and it is made in America! With proper care and maintenance, it will provide long and dependable service.

This Manual contains safety suggestions and important instructions regarding this equipment. Read this Manual thoroughly and retain for future reference.

IMPORTANT NOTICE

If replacement parts are required, use only genuine original equipment parts. **DO NOT** use unauthorized parts or substitute materials.

Generic Symbols:

The following groups of symbols are used in this manual to help communicate the intent of the instructions. When one of the symbols appears, it conveys the meaning defined below.



Safety Alert - Serious injury or damage can result if instructions are **not** followed.



Hourly Service Interval.



Unacceptable (NOT OK) Condition.



Caution - Chemicals are corrosive to operator and equipment



Inspection Required.

Safety



THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

IMPORTANT:

United States Government safety standards have been adopted under the Occupational Safety and Health Act. These standards, particularly the General Standards, Part 1910, and the Construction Standards, Part 1926 - should be consulted in connection with your use of airless spray equipment.

Safety Rules



We can not anticipate every possible circumstance that might involve potential hazard. The warnings, cautions and safety suggestions in this manual are therefore not all inclusive. If an operating procedure, installation, maintenance or work method not specifically recommended is used, you must satisfy yourself that it is safe for you and other persons. You must also ensure that the product will not be damaged or be made unsafe by the procedure that you choose.

A

Warning:

Fluids under high pressure spray can be nearly invisible and can penetrate the skin and cause extremely serious injury!

If any fluid appears to have penetrated the skin, get emergency medical care at once! Do not treat it as a simple cut. Tell your doctor exactly what fluid was injected. For treatment instructions, have your doctor call the:

National Poison Control Network (412) 681-6669

- Never put hands or fingers over the spray tip(s) while in operation.
- Never attempt to stop the rotating tubes and tips with your hands or any other object.
- **Never** tip the spinner backwards while in use.
- Never attempt machine repairs or adjustments while machine is hot.

- Never use any caustic chemicals or solvents as serious damage to the rotating union may result. If chemicals are used, a thorough flushing with clean water should immediately follow.
- Never point the spray gun, when used in conjunction with the pressure washer's lance and spray tip, at other persons or at any part of the body.
- Never attempt to push machine over hose while tubes are spinning.
- Never use the spinner on any uneven surfaces as this could cause serious damage to the machine and the operator.
- Always shut off the pressure washer and trigger the pressure gun to relieve system pressure before removing the spray tips or before performing any machine service.
- **Never** operate the machine if any vibration is present.
- Never run over bags, cups, paper, or other debris or garbage.
- Never alter or modify this equipment! Your personal safety as well as the safety of other persons is at stake.
- Always wear full eye protection, protective clothing, gloves and rubber boots when operating the machine to protect yourself from burns caused by hot spray, fluid injection or debris dislodged by high pressure spray.

Safety



Discharge Hose Warning

- Always operate the machine on level and horizontal surfaces. Never try to use machine on vertical or pitched surfaces such as walls or roofs.
- Always replace spray tubes with factory authorized replacements when necessary.
- Never leave an operating machine unattended. Always shut off the machine and relieve pressure before leaving the machine.
- Always keep guards or shields in place. Replace any that that must be removed for service or that may be damaged.
- Do Not attempt repairs or modifications you do not understand. Contact your servicing dealer or contractor.
- Never exceed the factory pressure or temperature rating of the spinner.
- Never operate the spinner unless the orifice size of a spray tip in the spinner, multiplied by the number of tips in use by the spinner, is equal to or greater than that required to operate the pressure washer at its manufacturer's rated specifications.
- Never operate the Spinner with different orifice size spray tips.
- Never operate the spinner if one or more spray tips are plugged or if spray tubes are damaged.
- Never allow the spinner to operate in one spot for extended length of time. Damage to the surface may occur.

The discharge hose supplied with the machine is designed for use on high pressure cleaners and accessories. Special care, handling and maintenance are required to provide proper and safe operation. The following guidelines must be followed to ensure safe operation and provide maximum hose service life.

- Do Not route hose in a manner that will cause sharp bending, kinking, cutting, abrasion or other exterior damage.
- Do Not use the hose if cuts, leaks, abrasions, bulges or coupling damage is evident.





- Do Not attempt field repairs through an unauthorized hydraulic hose repair shop. Special coupling and crimping specifications are required for steam and high pressure washer discharge hose. Contact a qualified pressure washer service representative for repair of damaged hose.
- Always examine hose couplings and quick disconnects (if used) before each operation. If leaking is evident, do not use. Contact a qualified pressure washer service representative.

Specifications —

Maximum Recommended Pressure	4000 PSI
Maximum Flow Rate	5 GPM
Minimum Recommended Pressure	1500 PSI
Minimum Recommended Flow Rate	2 1/2 GPM
Maximum Temperature (F°)	250°(F)
Maximum Rotational Speed	2000 RPM
Cleaning Path	16"
Dimensions Length Width Height	52" 19" 37"
Approximate Weight (Lbs)	15 1/2 Lbs



For Your Safety and the Safety of Others, Study This Manual Before Operating or Servicing the Machine.

Machine Delivery Inspection

Examine the shipping carton and machine carefully for hidden damage during shipping. Claims for damage or shortage should be filed with the contract carrier. Remove all loose parts and strapping attached to the machine for shipping purposes.

Machine Identification

The machine serial number is on a plate permanently attached to the Spinner. Record the serial number from this plate for any future reference.

SERIAL#

Machine Location

The Spinner is designed to be used in conjunction with a hot or cold high pressure washer to quicken the cleaning of large level surfaces. It is not designed for use on vertical or pitched surfaces such as walls or roofs.






Figure 1

Item List

Item #1 – Trigger Gun

Item #2 – Gun Outlet Quick Coupler (Attached to Trigger Gun)

Item #3 – $\frac{1}{4}$ " x 50" Hose (Attached to lower handle)

Item #4 – Upper Handle Assembly

Item #5 – Lower Handle Assembly

Item #6 – 5/16" X 1 3/4" Bolt

Item #7 – 5/16" Four Prong Knob

Item #8 – Deck Assembly

	Tools Requ	<u>ired</u>
One 1/2" Wrench	Or	One Adjustable wrench

Machine Assembly

- 1. Remove all parts from the carton and verify contents against the item list. If there are any shortages, please contact your seller.
- 2. Place Item #4 (Upper Handle Assembly) upside down (Rubber handle grip pointing up) on a flat surface such as the floor, bench top or table top.
- 3. Slide Item #5 (Lower Handle Assembly) inside Upper Handle Assembly so that the 5/16" holes line up and hose points downward.
- 4. Insert Item #6 (5/16" bolt) through hole in handle and thread on Item #7 (Four Prong Knob.)
- 5. Connect Item #3 (1/4" Hose) to the quick coupler on the bottom side of the Upper Handle Assembly.
- 6. Place Item #8 (Deck Assembly) on a flat surface such as the floor, bench top or table top.
- 7. Slide Connector at the bottom of the Handle Assembly onto the threaded connector on the Deck Assembly. Turn Clockwise to tighten.
- 8. Connect Trigger Gun to Handle Assembly

Recommended Machine Set-up



Ensure pressure washer is turned off before proceeding.

- 1. Remove the gun and lance that is attached to your pressure washer.
- 2. Connect Hose to Surface Spinner using 3/8" Quick coupler



IMPORTANT: The spinner is supplied with (2) 15° #2.5 orifice spray tips. Be sure that this size is compatible with the flow and pressure specifications of your pressure washer. **Never** allow the spinner to be used if the orifice size in the Spinner, multiplied by the number of arms in use, (in this case 2 x #2.5 orifices equal a #5) is less than the orifice size required to operate the pressure washer at its manufacturer's specifications. Serious personal injury as well as damage to the pressure washer may result if over pressurization occurs.

Machine, Start-up and Use

- 1. Start the pressure washer, being sure to follow all manufactures instructions concerning start-up.
- 2. Pull back on Trigger Gun Handle. Begin pushing the spinner forward. Walk at a pace that allows the Spinner enough time to clean as thoroughly as you require.

Operating Tips and Procedures

1. Identity the surface that is to be cleaned.

There are many different types of surfaces that can be cleaned with the Spinner. Therefore it is very important that before you begin, you properly identify the surface that is to be cleaned. Each surface has its own characteristics that must be taken into account. A typical example would be the difference between a muti-level parking garage and a cement patio. Both are cement, but the parking garage cement typically is three times as strong as the patio. Therefore, if you are using a very high pressure washer, damage to the softer concrete may result. In order to avoid what could be a costly mistake, always perform thorough identification and inspection procedures.

There are a number of other items that you must be aware of when inspecting the job site. Potential problems areas must be identified before beginning work, such as cracked or fractured surfaces, anchor bolts, holes, rocks, uneven surfaces, etc. Any one of these can cause damage to the Spinner. Therefore, it is recommended that you identify potential problem areas and mark them so that you can avoid these areas and possible damage to your Spinner.

2. Identify the type of soil to be removed.

In order to maximize the performance of the Spinner, you must properly identify the type of soil that is to be removed. Typical sidewalk soils such as soda pop, candy and food would require minimal chemical preparation as opposed to degreasing a parking space which would typically require a presoaking with an industrial degreaser. No matter what the circumstances are, thorough identification is important.

3. Determine if a chemical is necessary and if so, which chemical is right for the job.

Once you have determined the type of surface and soil, you must determine if a chemical treatment is necessary. If a chemical is in fact necessary to loosen soil, be sure to include it in the test patch which will be discussed in section 5. Once again it is very important to identify the soil and prepare the surface with the proper chemical as this will assist you in maximizing the performance of the Spinner.

4. Chemical application.

There are two methods of applying chemicals to surfaces. The most common method is by utilizing a Hudson sprayer or something comparable. This method allows the highest concentration of chemical to be applied directly to the soiled areas. The second method is by pumping the chemical through the Spinner forcing the chemical onto the soil under high pressure. Either method is acceptable and results will vary from job to job. If you choose to run chemical through the Spinner, you must flush the system for at least 5 minutes with clean water in order to make certain that there is no chemical remaining in the union. Failure to thoroughly clean the system can cause substantial damage to the union and void the warranty. The use of any acids through the Spinner also voids the warranty.



CHEMICALS ARE CORROSIVE TO OPERATOR AND EQUIPMENT. THOROUGHLY FLUSH EQUIPMENT AFTER USE. IF OPERATOR COMES IN CONTACT FLUSH AREA WITH CLEAN WATER AND SEEK MEDICAL TREATMENT.

5. Perform a test patch.

Once you have all the information necessary to proceed, pick a small inconspicuous area to perform a test patch. When choosing the test area, make certain that it is consistent with the general area to be cleaned. Next, connect the high pressure hose from the Spinner to the port of the trigger gun. Pull the trigger to establish flow. With a smooth and steady motion, walk slowly forward approximately 5 feet. Release the trigger assembly and inspect the surface.

REMEMBER: You must include all factors when performing a test. Do not forget to turn on the burner if using hot water. Also apply chemical if inspection determined it is necessary.

6. Operating Tips and Procedures

Establish cleaning pattern.

Just as you would create a pattern when mowing a lawn, you should create a pattern with the Spinner. There are several factors that you must take into consideration when determining the starting point.

- A) Establish a pattern that allows water to flow away from the immediate work area. This will eliminate as much standing water as possible.
- B) If possible, start at the highest point and work toward the lowest point. Do not attempt to operate the Spinner through standing water as the effectiveness of the spray is dramatically reduced and possible damage to the Spinner could result.

Helpful Hints:

- 1. Try and route the hose so it is always to your back. This will eliminate having to constantly move it out of the way.
- As you complete your first pass, you will most likely turn around and parallel that path back to the starting point. If you turned to the left at the end of the first path, turn right at the end of the second path. This will keep your hose from coiling up.

Routine Maintenance



A Properly Maintained Machine Is A Safe Machine

It is the operator's responsibility to make daily inspections of the machine for anything that could cause a potential service or safety problem.

Service & Maintenance Schedule

Preventative maintenance is the easiest and least expensive type of maintenance. The life of any machine depends on the care that it is given. A regular inspection of the machine's systems and critical components is the key to preventative maintenance. To prevent machine down time and prolong the life of your unit, follow these simple routines.



Daily

Check spray tubes for bending or damage. Check wash nozzles for clogging or damage.



Weekly

Check pressure hose for wear or damage. Check quick couplers for leakage (if used). Check in-line swivel for leakage (if used). Check wheels and replace when necessary.

Troubleshooting



WARNING: Before Attempting Any Repairs or Maintenance, Be Sure Machine is Shut Off and Disconnected from Main Pressure Washer.

Troubleshooting

Troubleshooting is an organized study of the problem and a planned method of procedure for investigation and correction of the difficulty. The following troubleshooting guide includes some of the problems that you may encounter during the service life of the machine.

This troubleshooting guide does not give all the answers for correction of problems listed, but are meant to stimulate a train of thought and indicate a work procedure directed toward the source of the trouble.

THINK BEFORE ACTING

Study the problem thoroughly and ask yourself these questions:

- 1. What were the warning signs preceding the trouble?
- 2. What previous repair and maintenance work has been done?
- 3. Has a similar problem occurred before?
- 4. If the machine still runs, is it safe to continue operating to make further checks?

DO THE EASIEST THING FIRST

Most problems are simple and easily corrected.

Example: "Nozzles will not spin." Complaint caused by plugged nozzles or improper angle.

Always check the easiest and obvious things first. Following this simple rule will save time and money.

FIND AND CORRECT BASIC CAUSE OF TROUBLE

AFTER A MECHANICAL FAILURE HAS BEEN CORRECTED, BE SURE TO LOCATE AND CORRECT THE CAUSE OF THE PROBLEM SO THAT THE SAME FAILURE WILL NOT BE REPEATED.


The following pages list some of the problems, causes and probable fixes the operator can study to become aware of what might cause the problem should it arise.

If the hints in this manual do not correct a problem, contact a dealer or authorized service representative. **DO NOT** attempt repairs you do not understand.


____ Troubleshooting

PROBLEM	PROBABLE CAUSE	POSSIBLE REMEDY				
1. Machine Vibrates.	1. Plugged nozzle(s).	Remove nozzle, inspect for debris, remove obstruction, replace nozzle.				
	2. Bent tubes.	Inspect manifold assemble for damaged tubes. Replace damaged tubes as necessary.				
	3. Worn or damaged union.	Inspect union for play in the shaft. Replace union if necessary.				
	4. Different size spray nozzles.	Make sure the nozzles are of equal orifice size.				
	Wheels or wheel brackets are loose or damaged.	5. Inspect and repair as necessary.				
2. Nozzles will not spin.	1. Plugged nozzle(s).	Remove nozzle, inspect for debris, remove obstruction, replace nozzle.				
	2. Rotating union has failed.	Inspect union and replace as necessary.				
	3. No pressure to Spinner.	Check for pressure at pressure washer.				
3. Spinner will not turn.	1. Debris has attached to front wheel.	 Inspect wheel for rock or other foreign object. 				
	2. Lack of adequate lubrication.	2. Grease rear wheel.				


Illustrated Parts List



Illustrated Parts List



Illustrated Parts List -



Illustrated Parts List

		16" Little Floater Surface S	oinner PARTS LIST						
Item	QTY	Part description	Part number						
1	1	Trigger Gun	06-152500						
2	1	Quick Coupler	01-421010						
3	1	Quick Coupler Nipple	01-421310						
4	1	Handle Assembly	BSE-1005-1						
5	1	16" Deck Assembly	BSE-1009	BSE-1009					
		Break down of Handle Asse	mbly (BSE-1005-1)						
6	1	Handle Grip	06-201001						
7	1	Quick Coupler Nipple	01-421110						
8	1	Quick Coupler	01-421010						
9	1	Quick Couple Nipple	01-421100						
10	1	Hose	11-115022						
11	1	Upper Handle Weldment	BSE-1010						
12	1	Lower Handle Weldment	BSE-1011						
13	1	Bolt, 5/16" x 1 1/2"	02-121400						
14	1	Knob	02-541070						
15	1	Twist Connect Body	01-201001	01-201001					
	·	Break down of Deck Asse	mbly (BSE-1009)						
16	1	Twist Connect Plug	01-201000						
17	1	Union, 16" HD Spinner	01-171704	01-171704					
18	1	Caster Mount Bracket	BSE-1008						
19	9	Nut, Nylock, 1/4"	02-301130						
20	9	Bolt, 1/4" x 3/4"	02-111100						
21	3	Caster 2"	12-101010						
22	6	Locknut, Serrated, 7/16"	02-301350						
23	1	Deck 16" Spinner 23-101501-4							
24	1	Brush Assembly	BSE-1007						
25	5	Rivet, Pop	02-522200						
26	1	Spray Arm	01-171705						
27	2	Wash Jet, 1502.5	06-100460	06-100460					

Reference

	4000	3	3	3	3	3	3	3	3	4	4	4	4	4	9	9	2
	3800	3	3	3	3	3	3	3	3	4	4	4	4	2	2	2	2
	3600	3	3	3	3	3	3	3	4	4	4	4	4	2	2	2	2
	3400	3	3	3	3	3	3	3	4	4	4	4	2	2	2	2	5
	3200	3	3	3	3	3	3	4	4	4	4	4	2	2	2	2	9
	3000	3	3	3	3	3	3	4	4	4	4	2	2	2	2	9	9
Rating	2800	3	3	3	3	3	4	4	4	4	5	2	2	2	2	9	9
Pressure Rating	2600	3	3	3	3	4	4	4	4	4	5	2	2	2	9	9	9
•	2400	3	3	3	4	4	4	4	4	2	5	2	2	9	9	9	9
	2200	3	4	4	4	4	4	4	2	2	2	2	9	9	9	9	7
	2000	4	4	4	4	4	4	2	2	2	5	9	9	9	7	7	7
	1800	4	4	4	4	4	4	2	2	2	9	9	9	7	7	7	7
	1600	4	4	4	4	2	2	2	2	9	9	9	7	7	7	8	8
	1500	4	4	4	2	2	2	2	9	9	9	7	7	7	8	8	8
		2.5	2.6	2.7	2.8	2.9	3	3.2	3.4	3.6	3.8	4	4.2	4.4	4.6	4.8	5
			2.6	2.7	2.8	2.9	3	3.2	3.4	3.6	3.8	4	4.2	4.4	4.6	4.8	ц

Total No

Flow Rate

Hose Friction Loss




Chart shows amount of pressure lost per 100' of hose independent of original pressure.



Warranty

We warranty each new unit and part sold by us to be free from manufacturing defects in normal service for a period of six (6) months commencing with delivery of the product to the original owner. Copy of the original bill of sale, including serial number must accompany claim.

Our obligation under this warranty is expressly limited at our option to the replacement or repair at a facility designated by us, of such part or parts as inspection shall disclose to have been defective. This warranty does not apply to defects caused by damage or unreasonable use (including failure to provide reasonable and necessary maintenance) while in the possession of the customer. THIS WARRANTY DOES NOT APPLY TO HARDWATER DAMAGE, NOZZLE WEAR, PAINT, OR IMPROPER CHEMICAL USE.

Equipment which or that proves to be defective upon our inspection will be repaired or replaced at our discretion, F.O.B., Steel Eagle, Inc.

WE SHALL NOT BE LIABLE FOR CONSEQUENCIAL DAMAGE OF ANYTHING, including but not limited to, consequential labor costs or transportation charges in connection with the replacement or repair of defective parts.

Components including but not limited to, which are manufactured by other vendors, will be subject to warranty terms to their own warranty.

Failure to use circuit breaker with any electric rewind motor will void warranty on motor. Failure to use flexible connectors with any live hose reel will void warranty on the swivel.

ANY IMPLIED OR STATUTORY WARRANTIES, INCLUDING ANY WARRANTY OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. We make no other express warranty, nor is anyone authorized to make it on our behalf.

Steel Eagle, Inc. 32586 477th Ave. Elk Point, SD 57025 Ph: (800) 447-3924 Fx: (605) 356-2144 www.steeleagle.com info@steeleagle.com



Steel Eagle, Inc. 32586 477th Ave. Elk Point, SD 57025 Ph: (800) 447-3924

Fx: (605) 356-2144 www.steeleagle.com info@steeleagle.com

ASE-0018 Revision 01-25-08